# Fuse holder guide

What's the difference between all of our service fuses? Which fuse goes in which fuse holder? Click on any image or code to view the item in store.

### **Switchboard mounted type**




### 04278

100A fuse holder front wire



### 08762

100A fuse holder back wire





### 09292

100A fuse holder front wire



#### 08750

80A 30x57mm service fuse





#### 07562

100A fuse holder front wire



### 09293

100A fuse holder back wire



## 03847

100A 30x57mm service fuse

### Pole mounted type



### 05360

100A fuse holder K series 6 - 95mm<sup>2</sup>



### 06587

100A fuse holder PFV series 6 - 95mm<sup>2</sup>



### 04202

80A 22x58mm service fuse





### 02582

100A fuse holder K series 6 - 35mm<sup>2</sup>



### 08705

100A fuse holder PFV series 6 - 35mm<sup>2</sup>





### 02414

100A 22x58mm service fuse



### 03535

Mounting bracket for K series



### 08706

Mounting bracket for PFV series

### Pit type



### 09319

Waterproof pit fuse holder



### 04202

80A 22x58mm service fuse

### OR



### 02414

100A 22x58mm service fuse